

WARNING: disconnect main power at the source prior to installation!

Only qualified electricians should install Delray Lighting products.

- 1 Drill two mounting holes, 2.75" apart.
- 2 Mount canopy to J-Box or directly to conduit and complete wiring connections to ballast.
- 3 Attach fixture to canopy with two side screws.
- 4 Insert lamp into socket and twist lock into place.

