



**Note:**  
Power enters through lower arm only.

**WARNING:**

Disconnect main power at the source prior to installation!  
Fixture must be installed by a qualified electrician.